

**trotec**<sup>®</sup>


*laser. marking cutting engraving*



# → Operation Manual

Trotec JobControl<sup>®</sup>

Basic, Advanced, Expert



JobControl<sup>®</sup> 10.7\_EN (01/2017)

ENGLISH

Translated manual

**Trotec Laser GmbH**

Linzer Straße 156  
A – 4600 Wels  
AUSTRIA

**Trotec Laser GmbH**

Freilingerstraße 99  
A – 4614 Marchtrenk  
AUSTRIA

Tel.: +43-(0)7242-239-0

[trotec@troteclaser.com](mailto:trotec@troteclaser.com)  
[www.troteclaser.com](http://www.troteclaser.com)

Technical  
Changes

Technical specifications are subject to change without notice.  
Trotec Laser GmbH reserves the right to improve or modify any of the  
product without prior notice.

© Copyright

This documentation with all illustrations is intellectual property of  
Trotec Laser GmbH. The entire documentation is given to the user for per-  
sonal use only. Reproduction, translation or any distribution to third parties is  
not permitted without the prior consent of Trotec Laser GmbH. Any breach of  
law will be prosecuted.

## CONTENT

<b>1 General .....</b>	<b>5</b>
1.1 Computer Requirements .....	5
1.2 Installation of the engraver driver .....	6
1.3 Installation of Trotec JobControl® .....	6
1.4 JobControl® Software Registration .....	6
1.5 Share registration keys with other users .....	9
1.6 Compatibility.....	10
1.7 The Software Concept .....	10
<b>2 Engraver Driver .....</b>	<b>11</b>
2.1 Overview .....	11
2.1.1 Basic Driver.....	12
2.1.2 Advanced Driver .....	14
2.1.3 Expert Driver .....	15
2.2 Favorites.....	15
2.3 Size Settings .....	17
2.4 Material Settings .....	18
2.5 Process Options .....	19
2.5.1 Process Mode.....	19
2.5.2 Resolution .....	21
2.5.3 Cut Line.....	22
2.5.4 Halftone.....	23
2.5.5 Checkboxes .....	24
2.6 Control Functions .....	26
<b>3 Material Database .....</b>	<b>28</b>
3.1 Overview .....	28
3.1.1 Process .....	28
3.1.2 Power.....	29
3.1.3 Speed.....	29
3.1.4 PPI .....	29
3.1.5 Hz.....	30
3.1.6 Auto.....	30
3.1.7 Passes .....	30
3.1.8 Air Assist .....	30
3.1.9 Z-Offset .....	30
3.1.10Direction .....	31
3.1.11Path planning .....	31
3.1.12Advanced .....	32
3.2 Create material group .....	33
3.2.1 Hierarchical material groups .....	33
3.3 Create / rename / delete material .....	33
3.4 Lock material .....	34
3.5 Material Settings .....	36
3.6 Make Color order changeable.....	37
3.7 Unique description for processes .....	37
<b>4 Trotec JobControl® .....</b>	<b>39</b>

4.1 Overview .....	39
4.2 Laser Control Functions .....	41
4.3 Job Preview .....	42
4.4 Drag snap lines .....	43
4.5 Side Bar .....	43
4.6 File .....	45
4.7 Edit .....	45
4.8 Engraver .....	46
4.9 Plate .....	47
4.9.1 File Format .....	47
4.9.2 Material choice .....	48
4.9.3 Material priority .....	48
4.9.4 Plate Setup .....	48
4.9.5 Job Positioning .....	49
4.9.6 Ordering of Vectors .....	50
4.9.7 Jobs .....	50
4.9.8 Marker .....	51
4.10 Settings .....	51
4.10.1 Templates .....	51
4.10.2 Options .....	52
4.10.3 Create Service File .....	53
4.10.4 Information .....	54
4.10.5 Update Firmware .....	54
4.11 Options Dialog .....	56
4.11.1 General .....	56
4.11.2 Hardware .....	59
4.11.3 Process options .....	66
4.11.4 Service .....	75
4.12 View .....	84
4.12.1 Status Bar .....	84
4.12.2 Toolbar JobControl® - Advanced .....	84
4.12.3 Toolbar JobControl® - Expert .....	85
4.12.4 Zoom .....	85
4.12.5 Job Position .....	86
4.12.6 Material Parameter .....	86
4.12.7 Laser Position .....	87
4.12.8 Lens Toolbar .....	87
4.12.9 Software Autofocus Toolbar .....	87
4.12.10 Safe Position .....	88
4.12.11 Job Queue .....	89
4.12.12 Engrave Time Calculation .....	91
4.12.13 Properties .....	93
4.12.14 Vectors .....	94
4.12.15 Job History .....	95
4.12.16 Recycle Bin .....	95
4.12.17 WYSIWYG on/off .....	96
4.13 Window .....	97
4.14 Help .....	97

4.15 List of available shortcuts .....	98
<b>5 JobControl® Vision.....</b>	<b>100</b>
5.1 Overview .....	100
5.2 Hardware Guide .....	101
5.2.1 Vision Camera .....	101
5.2.2 Camera Connection.....	102
5.2.3 Camera LED adapter.....	103
5.2.4 Removing of the camera .....	105
5.2.5 Camera Sharpness Adjustment.....	106
5.3 Supported Applications .....	106
5.4 Workflow How-to .....	107
5.5 Vision Configuration .....	117
5.6 Camera Offset Calibration .....	119
<b>6 Graphics Software .....</b>	<b>123</b>
6.1 Contours and Fills .....	123
6.2 Image Processing Order .....	123
6.3 Overlapping Fills .....	123
6.4 Overlapping Outlines.....	123
6.5 Hidden Vectors in Graphics .....	124
6.6 Power Control through Color Selection .....	124
6.7 Bitmap and Vector Images.....	125
6.8 Scanning of Pictures .....	125
6.9 Image tracing.....	125
6.10 Multicolor Option - MCO2 .....	125
<b>7 Index.....</b>	<b>127</b>

## 1 General

### 1.1 Computer Requirements



The following recommendation represents the minimum requirements.  
 When using a more powerful computer the graphics are generated and displayed faster  
 and the computing times and the data transfer to the laser are reduced.  
 Please note that due to the rapid rate of change in information technology, we anticipate  
 that hardware and software competencies will be updated on a regular basis.

- Operating systems
  - Windows 10® 32/64-bit
  - Windows 8® 32/64-bit
  - Windows 7® 32/64-bit
  - Windows Vista® 32/64-bit (with Service Pack 1 or later)
- Microsoft® .NET framework 3.5
- Adobe® Reader 9.0 or later
- Local administrative privileges (for required software installations)

- GHz processor or faster
- 2 GB RAM or greater (Windows Vista®, Windows 7 / 8 / 10)
- 80 GB hard drive or larger
- 1024 x 768 resolution monitor or greater
- True color graphics card (24-bit color depth)
- 2 free USB interfaces
- DVD-ROM drive

## 1.2 Installation of the engraver driver



The installation of the printer driver enables communication of the graphics software with the Trotec JobControl® version (Basic, Advanced, Expert). This driver is installed automatically during the installation of JobControl®.

## 1.3 Installation of Trotec JobControl®




The JobControl® software serves for easy operation of your engraver. All functions of the engraver can be controlled and all settings can be performed from the computer. The permanent communication between JobControl® software and engraver provides for a smooth flow of the operation process.

The following installation instructions give you a short overview over the installation of the JobControl® software. For detailed instructions on the operation of Windows® please refer to the Windows® user guide.

1. Start Windows®.
2. Insert JobControl® Software DVD into the first DVD-ROM drive.
3. Press "Start" and then on "Run". Press "Browse" and double-click on setup.exe. The program now starts the installation routine and copies all necessary data to the hard disk.
4. This completes the installation. Keep the JobControl® DVD-ROM in a safe place.

## 1.4 JobControl® Software Registration

When you launch JobControl® for the first time, you will be asked to register the software.




In order to use JobControl® you will have to enter two codes:




1. View code
2. Activation code

To use the camera feature of JobControl® you have to enter the JobControl® Vision Code.


The registration codes are indicated on the document in the JobControl® box delivered together with the machine:



After every code entry the JobControl® enables the desired module.



Once the registration of the feature has been finished, the following dialogue appears:




In order to use JobControl® the code for view and activation must be entered. See software registration dialogue. There you can also see the activation of JobControl® Vision.

Current user			
Key	Feature	Level	valid thru
View	Expert View	unlimited	
JobControl® Vision	full	unlimited	
Activation Key	enabled	unlimited	
Multi Color Option	-	-	
Vector ordering	-	-	
JobControl® Cut	-	-	

## 1.5 Share registration keys with other users


With the software registration dialog it is possible to share the registration keys with other users of the computer were the software is installed. The owner of the key can decide which keys to share.

To be able sharing the keys it might be necessary to start the JobControl® in administrator mode.



In the following example the View and Activation Key were dragged into the "All users" area of the software registration dialog. Now every user can use JobControl®.

The vision is still inside the "Current user" window. Therefor it can only be used by the owner of this key. Still every other user has the possibility to enter a key to enable JobControl®.Vision.



## 1.6 Compatibility



For smooth interaction of different Trotec software it is very important to use identical versions. The first two digits must match. Just the last version number is unimportant (X.X.X).

Example: MCI-Check 10.0.x needs JobControl® 10.0.x;  
JobControl® 10.7.x needs Trotec Driver 10.7.x

Affected software is JobControl®, Trotec Printer Driver, MCI-Check and UniDrive.

## 1.7 The Software Concept

The Trotec software package consists of two parts, the

- Trotec Driver (Engraver driver) and the
- Trotec JobControl®





The Trotec Driver creates a printing job from any graphics program for the Trotec JobControl®. This printing job contains the graphic data with the selected resolution and also information, whether it is a rubber die or an engraving job.

In case of a rubber die the graphic data is automatically inverted and mirrored and an optimized cutting line is defined. In the engraver driver you can also select from a number of pre-defined printing templates (plates) (e.g. Stamp 4911), which essentially simplifies operation. The printer driver places the printing job (file) into a pre-defined directory, which is automatically accessed by the JobControl<sup>®</sup> Manager Software.



In the Trotec JobControl<sup>®</sup> the printing job is positioned on a plate and engraved with predefined material parameters. The Trotec JobControl<sup>®</sup> is responsible for the control of the engraving system. With the new Trotec System you can continuously control the engraving progress and important status messages on the screen of your computer.



## 2 Engraver Driver

### 2.1 Overview

The driver transfers the graphic into a legible file for the engraver.


The file format for the engraver is \*.TSF which stands for **Trotec Spool File**



In addition, all driver settings are saved in this file. Using this information the engraver knows how to process the job.

## 2.1.1 Basic Driver

This is the basic version.



The driver allows you to conveniently carry out the required process, process options, size and material settings all on one page.



NOTE: after printing the job the driver prints this automatically in "Quick Print" only, other sophisticated options are not included in this Version like e.g. Rotary attachment, Auto position and so on...


### Process Mode and Size Settings for Basic Driver

Process = the type of processing. The process selected is displayed in the form of a symbol in the driver's properties window.


<b>Size Settings</b>	<b>Process Mode</b>	<b>Process Option</b>
User-defined Size	Standard	500dpi Resolution
Width 96.00 mm	Standard	medium Shoulder
Height 96.00 mm	Stamp	

## 2.1.2 Advanced Driver

This is the advanced version



### 2.1.3 Expert Driver



As above in this version we can see many sophisticated options which are not available in basic and advanced Drivers.

### 2.2 Favorites

It is possible to save printer driver configurations in the favorites archive.  
 Save printer driver configurations in the print tab.



### Engraving

 Opens the dialog to load favorites.



Load printer driver configurations in the favorites tab.

This screenshot shows the printer driver configuration window with the "Favorites" tab selected. The top navigation bar includes "General", "Favorites", and "Print". The main area displays a table of printer configurations:

Name	Process Mo...	Resoluti...	Size Settings (m...
Standard	Standard	1000dpi	Minimize to Jobs...
RGV	Standard	1000dpi	Minimize to Jobs...
★ Engraving	Standard	1000dpi	Minimize to Jobs...

Below the table are two buttons with icons: a blue star and a red star. At the bottom are two large buttons: a blue one with a "JC" logo and a grey one with a red "X".



Load the marked configuration.



Delete the marked configuration.

## 2.3 Size Settings

The selection window allows you to open predefined size templates. This will quickly make frequently used job sizes available.




### Width, Height

Dimensions of the size template currently opened are displayed either in millimeters or inches (adjustable in the JobControl® options).

If the entries in these fields are manually changed, the selection window displays "user-defined-size".



The button left to the Size Templates opens the dialog where new templates can be created or existing templates can be changed.



### Take from Application

Printer driver gets job size from application.

Only works with software supporting this function. (E.g. CorelDraw X5 and later versions)


### Minimize to Jobsiz

Printer driver minimizes Print width and height to artwork size.

To use this feature the width and height of the predefined settings template must be larger than the artwork width and height.

### Rotary Attachment

Is used to engrave cylindrical work pieces (e.g. glasses) using the rotary engraving facility.



The display of size/width is changed to circumference. The driver automatically calculates the work piece's circumference using the diameter entered and uses this circumference as new job width. This behavior is very well illustrated in the print preview of the graphics program.

### 2.4 Material Settings



 With this button the material database can be opened. In it the material groups are structuring the materials.

New materials and groups can be generated. There are 16 process colors to choose from.

The two most common process colors are shown next to the control buttons. While black is traditionally used for engraving, red is used for cutting.


 **P 50.00** Shows the laser power in % of the max power.

 **V 100.00** Shows the velocity in % of the max velocity.


 **W 500** Shows the pulse per inch in engraving processes or Hz in cutting processes.

## 2.5 Process Options

The printer driver has different process modes. These modes will change the parameter set in use. From which process modes one can choose depends on the selected engraver. Also the parameters will change with the selected engraver.



For the engravers SP2000 and SP3000 there are the processes Standard, Relief and Cut activated.



### 2.5.1 Process Mode

#### Standard



Is used for a large number of engraving and cutting jobs.

Depending on the material settings (see 0) and process options used, one or several design colors may be used for engraving or cutting.

## Stamp



and-white graphics) is performed.

The engraving color in the stamp process is always black. Depending on the material settings (see 0) used, any color is allowed for the cutting lines.

Is used for creating stamp text plates mainly made of rubber materials that can be engraved by a laser.

The data is automatically mirrored and inverted as it is required for the production of stamps.

In general, black is the recommended design color for this processing. When using color or gray-scale graphics, an automatic raster (conversion into black-and-white graphics) is performed.

## Relief



gray-scale images during printing.

This process is used for the creation of three-dimensional effects and requires preferably softer materials (e.g. soft wood) allowing high material removal in one pass.

This type of processing controls the laser power depending on the gray-scale value of the graphic. This means, white is processed without power, light areas with low power, dark areas with increased power and black with fully set power.

This requires an 8-bit gray-scale graphic (256 gray scale). Color images are automatically converted to

## Layer



passes determine how often a certain dot is engraved.

In addition a z advance (table height adjustment) may be entered in the process options. This z advance of 0.00 to 5.00 mm (0.000 – 0.196 inch) moves the processing table upwards between the engraving passes in order to maintain the correct focus.

This processing method allows three-dimensional engravings with particularly large height variation to be obtained.

With the layer process type, gray-scale graphics are engraved in several passes. The number of passes can be set in the range from 2 to 255 in the JobControl® configuration menu. When using this process, the existing gray-scale is divided into the number of passes defined. The gray-scale values are then engraved in the appropriate passes (alternating engraving in X and Y direction). The gray-scale value and the

## Photo optimized




With the photo optimized processing type, high resolution images or photos are printed with special settings to reach maximum quality. Keep in mind that Photo optimized jobs are always processed in high quality mode.

## Seal



This type of processing is used for seal processing. The grammage of the paper can be chosen.



The most common seal templates are predefined with 41x41, 51x51 and 51x25. If one of them is used the seal cutline is generated automatically.

## Cut Job



With this processing type the parameters are made ready for cutting. Additionally all elements inside the picture that are no cutting lines are eliminated. This makes the job smaller and faster.

### 2.5.2 Resolution

Selection of the required resolution in dpi (dots per inch). Equivalent to the lines to be engraved per inch (25.4 mm).

A higher value improves the engraving quality, but results in increased engraving depth and longer engraving time using otherwise identical parameters as the laser has to process accordingly more lines.



Setting range: 125, 250, 333, 500, 600, or 1000 dpi

The setting for standard engraving should be 500 dpi. The resolution to be selected largely depends on the material used as well as on the focal length of the lens.

### 2.5.3 Cut Line

Selection of automatically created cutting lines.

The type of the selected automatic cutting line is displayed as a symbol in the preview.



None – no automatic cutting line will be created



Rectangular – a cutting line will be created which follows exactly the job margin (size)



Circular – a circular cutting line will be created whose size is determined by the job size



Optimized – a cutting line will be created which adjusts to the contour of engraving contents. This reduces the dimensions of a stamp job to the required minimum measure without losing contents. This allows reducing the material required.

Automatically created cutting lines are always generated in red (second color in the Material menu; R=255, G=0, B=0). When using automatic cutting lines, please ensure that the activated cutting color is red and has the appropriate parameters.




Automatically created cutting lines have no effect on manual cutting lines (vectors) which may exist in the file.

E.g. automatic and manual cutting lines may be used together or separately.

If automatic and manual cutting lines are used together in the same job, the user should consider this when creating the graphics. Undesired overlapping of both cutting line types may occur.

The Cut Line: None driver setting does not suppress manually created cutting lines.



Here the different types of automatically created cutting lines are very clearly illustrated.

## 2.5.4 Halftone

Halftone = Conversion of gray-scale or color images into black-and-white images creating the impression of a gray-scale image through different dot sizes and dot pitches.

Halftone is not available in Relief and Layer processing types as these processes require gray-scale graphics and therefore half toning is not desirable.

### Ordered Dithering

Standard halftone setting, soft contrasts between the brightness gradients

### Stucki, Jarvis, Floyd Steinberg

Advanced Dithering algorithms for photo engraving

### Color

Deactivates half toning by the driver.

Is used when several engraving colors are to be employed or half toning has already been performed in the application program.

“Color” is not available in the Stamp Mode as black-and-white graphics are always required for creating stamps.

### Black & White

Threshold level is used to decide if printed pixel will get black or white.

## 2.5.5 Checkboxes

### Invert

Inverts all colors in the printed image

### Flip vertically

Flips the printed image vertically

### Flip horizontally

Flips the printed image horizontally

### Enhanced geometries

Vector data of the printed job contains vectors and arcs which improves the accuracy of round contours significantly. The drawing application has to provide Bezier curve output for the printer driver to use this feature.




This feature is activated automatically when printing regmark jobs. (JobControl® Vision)

### Inner geometries first

This parameter will bring the cutting lines inside the art work into a new order if the ordering requirements are fulfilled.


This means that the geometries built by vectors are only sorted if the geometries are clearly nested. If the case is not clear, the geometries will stay in the order given by the graphics application.

Example for a **clear** case:




The circle rests inside the rectangle. The geometries can be sorted and cutting will start with the circle.

Example for an **unclear** case:




It is not clear which object lies inside which one. The geometries will not be sorted.



The objects lie next to each other. The geometries will not be sorted.

Stronger then the principle of position is the principle of color. Therefor the vectors will be separated by color inside the \*.tsf file.

#### Shoulder



Only activated in the Stamp process.

The available options of shoulder types are steep, medium, flat and other, user definable, shoulder settings.

Shoulders are used to give letters and characters of a stamp text plate more stability at the base (see graphic on the left)

#### Layers

Only activated in the Layer process.

The number of engraving layers required (engraving passes) can be set between 2 and 255 in this field.

#### Z-adjust/L


Only activated in the Layer process.

Entry of the up movement of the table carried out once a layer is finished. Setting range: 0.00 to 5.00 mm (0.000 to 0.196 inch).

## 2.6 Control Functions

### Auto Position

Jobs, which were printed with Auto Position, are automatically positioned on the plate in the JobControl®. Any further Auto Position job will be added onto the plate to the next free space. This function is used to load the plate for later processing.



### Quick Print

If you select the Quick Print check box, jobs will be printed without job name and job number query, automatically positioned on the plate in the JobControl® and the engraver will start. The job will be deleted once the engraving is completed.

This allows a largely automated manufacturing process and reduces the required user actions to a minimum.



If engraver is not turned on, it is not possible to automatically process a Quick Print job. The job will be put into the job queue.

### Store Printer driver changes

Confirms and saves changes for further use.

### Discard Printer driver changes


Discards all changes and exits from the printer driver.



A job name and an optional job number must be entered at the end of the print settings.

< > " / ? | ; \ : must not be used in the job name.

The job created will be saved with this name and number and copied to the JobControl® where it will be displayed in the queue.




### 3 Material Database

#### 3.1 Overview



With this Button the material database can be opened inside JobControl® and PrinterDriver. Inside the database the material to be used for the job is chosen.

You can use predefined material settings to achieve the best engraving and cutting results. Trotec supplies a large number of standard materials that can easily be updated. New materials can also be added. For a better overview, materials are clustered into material groups.



#### 3.1.1 Process

Defines, for which process mode the color is intended.

To print a job successfully, the colors have to match the needed Process type before printing the job. If the process mode is incorrect, vector data may be interpreted as halftone data and vice versa. To increase processing performance, skip unused colors in the material settings.

##### Engrave, Engrave CO2, Engrave FLP, Engrave YAG

The color displayed in this line will be engraved; e.g., fills with this color are processed line-by-line using the parameters set.

Vector objects in this color will be ignored.

For Flexx Laser Systems the name of the cut process also defines the laser source (CO2, FLP, YAG)

**Cut, Cut CO<sub>2</sub>, Cut FLP, Cut YAG**

The color of this line is only for vectors - for cutting.

Vectors (line width of 0.001 mm or 0.00005 inches) drawn in this color are executed using the laser parameters set.

Fills of the same color will not be processed.

For Flexx Laser Systems the name of the cut process also defines the laser source (CO<sub>2</sub>, FLP, YAG)

**Positioning**

Color will be shown in the WYSIWYG view but is not going to be processed. This works as a positioning help e.g. to draw & print object frames

**RegMark**

This Color defines which contours are used for regmark detection.



The regmark color has to be activated previous to the printing process of the regmark job.

**Skip**

Any occurrence of this color in the job will not be considered with either fills or vectors.

---

**3.1.2 Power**

---

Percentage of the maximum laser power.

The engraving depth depends basically on the laser power and speed set. Increased power as well as decreased speed results in deeper engraving or cutting.

Adjustment range: 0-100% (100% is equivalent to the maximum power of the laser).

---

**3.1.3 Speed**

---

Percentage of the maximum speed.

Important: Cutting speed percentage relates to maximum engraving speed. This means that if your laser machine has a maximum engraving speed of 355 cm per second, setting of 1 % means 3.55 cm per second cutting speed.

---

**3.1.4 PPI**

---

Pulses per inch (laser pulses per inch).

This setting determines the number of laser pulses per inch emitted by the laser. This occurs depending on the position, e.g. the pulses are always emitted at the same interval irrespective the speed.

Adjustment range: 500 - 1000 PPI

Auto Setting calculates optimum PPI settings automatically.



To obtain a good result, the PPI value must be usually larger than or at least the same as the dpi setting of the printer driver (Process options – Resolution), e.g. a minimum value of 500 PPI should be selected for a resolution of 500 dpi.

Unlike the resolution in dpi, increase in PPI does not have an effect on the engraving time.

---

### 3.1.5 Hz

---

Frequency of laser pulses during cutting. This setting determines the number of laser pulses per second emitted by the laser.

Adjustment range: 1000 - 60000 Hz for CO2 systems,

10000 – 150000 Hz for YAG systems,

20000 – 80000 Hz for fiber lasers

Additionally YAG systems can use frequency mode for engraving.

---

### 3.1.6 Auto

---

Auto Setting calculates PPI or Hz Settings automatically.

---

### 3.1.7 Passes

---

This value defines how often a color will be repeated.

Repetition passes work for engraving and for cutting processes...

---

### 3.1.8 Air Assist

---

Allows activation and deactivation of the (optional) air injection for each color separately.

---

### 3.1.9 Z-Offset

---

Controls the Z-axis (table) during processing. This allows e.g. to engrave in focus or refocus work pieces with different height Levels. At the end of processing the table is brought in the same position it was before start. Values are possible from -5 mm / -0,197" (up) to 25 mm / 0,984" (down).



In case of job abort the z-Start position could not be restored. Refocus is necessary.

### 3.1.10 Direction

The engraving of a job can be done from the top to bottom or from the bottom to the top and alternating starting either in the front or in the back.

This process is helpful on some materials (e.g. laserable plastics or wood) and reduces time and efforts for cleaning.

Color	Process	Power	Speed	PPI/Hz		Auto	Passes	Air Assist	Z-Offset	Direction	Advanced
1	Engrave	20.00	10.00	20000 Hz		<input type="checkbox"/>	1	On	0.00	Top down	Default
2	Cut	20.00	10.00	20000 Hz		<input type="checkbox"/>	1	On	0.00	Top down	Default
3	Skip	---	---	---		<input type="checkbox"/>	---	---	---	Top down (Alternati	---
4	Skip	---	---	---		<input type="checkbox"/>	---	---	---	Bottom up (Alternat	---

**Top down:** From the back to the front

**Bottom up:** From the front to the back

**Top down (alternating):** The beginning position alternates but starts at the back for the first time.

**Bottom up (alternating):** The beginning position alternates but starts at the front for the first time.

### 3.1.11 Path planning

The path planning parameter do not exist for every machine. Currently the SP2000 and SP3000 have this feature installed.

The parameter can be changed for cutting processes, all other processes have a defined set of parameters.

Color	Process	Power	Speed	PPI/Hz		Auto	Passes	Air Assist	Z-Offset	Direction	Path planning	Advanced
1	Engrave	20.00	10.00	20000 Hz		<input type="checkbox"/>	1	On	0.00	Top down	---	Default
2	Cut	20.00	10.00	20000 Hz		<input type="checkbox"/>	1	On	0.00	---	Standard	Default
3	Skip	---	---	---		<input type="checkbox"/>	---	---	---	---	Standard	---
4	Skip	---	---	---		<input type="checkbox"/>	---	---	---	---	High Quality	---

**Standard:** Acceleration and jerk between High Quality and High Speed.

**High Quality:** Low Acceleration and jerk.

**High Speed:** High Acceleration and jerk.

### 3.1.12 Advanced

Correction	<input type="text" value="10"/> 
Links	<input type="checkbox"/>
High Quality	<input type="checkbox"/>
Raster correction	<input type="checkbox"/>

Most functions described herein can be globally set in the JobControl® configuration menu. Settings in this configuration menu have priority. This means that any functions activated in the configuration menu cannot be deactivated in the advanced material settings. However, it is possible do add functions as described below.

#### 3.1.12.1 Correction

Determines the minimum percentage of laser power of the selected laser power which is set during slow movement; for example around curves in vector mode or acceleration phase during engraving mode.

##### Vector mode:

If the setting of this value is too small, the lines will thin at the ends and in the radius or disappear completely. If the selected correction is too high, the width will strongly increase at the line ends and radius.

##### Engraving mode (Firmware > 10.09 is necessary):

If the setting of this value is too small, the borders of the engraved image disappear or get less ablated because of material or laser nonlinearity.

If the selected correction is too high, the borders of the engraved image get more ablated then the center of the image.

First step before using correction value is to identify correct power value:

- Start with correction value zero.
- Choose the engraving width that maximum velocity is reached. Engraving width should be more than 400 mm when velocity is 100 percent.
- Adjust the correction value until the desired appearance is constant over the full engraving width. Correction value 15 is a good choice very often.

#### 3.1.12.2 Links

Activates the link function for the used color. If links are activated globally in JobControl® configuration menu this setting is ignored.

Links are small uncut bridges between cut lines which prevent the work piece from falling through the work plate. Links are mostly used for cut lines for rubber stamps. General link settings can be defined in JobControl® configuration menu.

#### 3.1.12.3 IPC – Intelligent Path Control

IPC optimizes acceleration and velocity settings of cutting processes in case of performance and quality. IPC does not have any effect for engraving processes. IPC can be adjusted for best speed or best accuracy.



IPC needs perfectly adjusted correction value settings to avoid decreased laser power during vector acceleration phase.

### 3.1.12.4 High Quality

Color is processed with high quality mode which means every engraving line has the same length. This setting can lead to significantly increased processing time.

### 3.1.12.5 Raster Correction

Improves quality of engraving processes.

### 3.1.12.6 Start position

This means you can start engraving the job from the TOP to the bottom Or from bottom to the top. This process is helpful on some materials (e.g. laser able plastics or wood) and reduces time and efforts for cleaning.

**Alternating:** If there are chosen more than two passes, the engraving direction will alternate every 2<sup>nd</sup> pass.

## 3.2 Create material group

Add a new material group to your material database using either the create material group button, with a right mouse click or a shortcut. Give a name and hit enter. Material group is now saved and you can now add materials to this new group.

### 3.2.1 Hierarchical material groups

There is also the possibility to create a material group inside a material group. This works only for a depth of 1, which means that a group inside a group cannot have groups underneath.


## 3.3 Create / rename / delete material

Add new materials to your material database using either the create material button, with a right mouse click or a shortcut. You can either start with a blank material page or copy – paste existing materials and change parameters afterwards.


Materials can be renamed and deleted using the right mouse click.

### 3.4 Lock material


Materials can be prevented from changes by locking them. To do this, you must first set a master password (Configuration – Locking – Set master password). JobControl® now switches into the Admin Mode.



Now you can lock or unlock materials, material groups or the complete database. Any materials locked are indicated with a lock.




If requested, you can change from admin to normal mode via the material configuration button.



### 3.5 Material Settings

Within material database you can choose or edit material settings for different materials and applications.



#### Thickness

Displays the thickness of material either in millimeters or inches.

The value is used optionally to focus on the material surface via JobControl® using the automatic focus mode

#### Description

If required, text may be entered for each material here, such as supplier, order number, or processing information. (Line feed using Ctrl + Enter key)

#### Color

There are 16 different colors available which can be adjusted for different processes with different settings.

Move with the mouse over one of the color boxes to display the RGB color components (red/green/blue) at the bottom of the color column.

In addition, a CorelDraw® color palette specifically matched for Trotec lasers can be found on the installation DVD.

By setting the appropriate parameters, an area of application can be assigned to each color, for example black for engraving bitmaps, red for cutting vectors and blue for comments.

Engraving Process Colors are done first and then Cutting Colors are executed.


Processing priority within the same process (Engraving or Cutting): Color 1 then Color 2 then Color 3...

Color	Process	Power	Speed	PPI/Hz		Auto	Passes	Air Assist	Z-Offset	Direction		Path planning	Advanced
1	Engrave	20.00	10.00	500	PPI	<input type="checkbox"/>	1	On	0.00	Top down	---	---	Default
2	Cut	20.00	10.00	1000	Hz	<input type="checkbox"/>	1	On	0.00	---	Standard	---	Default
3	Skip	---	---	---	---	<input type="checkbox"/>	---	---	---	---	---	---	---
4	Skip	---	---	---	---	<input type="checkbox"/>	---	---	---	---	---	---	---

Example: Proceeding sequence: Black (Color 1), Blue (Color 3), Red (Color 2), Blue (Color 4)

### 3.6 Make Color order changeable

Inside the drop down of configuration button is the entry "Color order" there the item "Make color order changeable" can be selected. If selected the order of the process colors can be changed.




To change the position of a color click it and drag it onto the desired position. Drop it there. The only color that can not change its position is black. It is fixed on its position.

To bring the colors into their original ordering scheme, select "Reset material color order changes ...".

### 3.7 Unique description for processes

To add an unique identifier to any process just activate the info column for parameters.



Enter the name for the process in the column that appears after activation.



Material database

## Standard / Standard

Color	Process	Power	Speed	PPI/Hz	Auto	Passes	Air Assist	Z-Offset	Advanced	
1	Engrave	Engrave	50.00	100.00	500 PPI	<input type="checkbox"/>	1	On	0.00	Default
2	Cut 1	Cut	50.00	2.00	2000 Hz	<input type="checkbox"/>	1	On	0.00	Default
3	Cut 2	Cut	30.00	1.00	1000 Hz	<input type="checkbox"/>	1	Off	0.00	Default
4	Skip	Skip	---	---	---	<input type="checkbox"/>	---	---	---	---
5	Skip	Skip	---	---	---	<input type="checkbox"/>	---	---	---	---
6	Skip	Skip	---	---	---	<input type="checkbox"/>	---	---	---	---
7	Skip	Skip	---	---	---	<input type="checkbox"/>	---	---	---	---
8	Skip	Skip	---	---	---	<input type="checkbox"/>	---	---	---	---

Thickness: 2.00 mm

Description:

Material Database Tree:

- ⊕ Glass
- ⊕ Goldring
- ⊕ Leather
- ⊕ MarkSolid Spray
- ⊕ Metal
- ⊕ Paper
- ⊕ Plastics
- ⊕ Plastics tromark
- ⊕ Plastics tromark cutting
- ⊕ Rubber
- ⊖ Standard
  - 1.8 S-300 120W
  - Seal Press
  - Standard

## 4 Trotec JobControl®


### 4.1 Overview

Trotec JobControl® has three different versions (Basic, Advanced, Expert).


The Trotec JobControl® carries out the following main tasks:

- Managing the jobs created by the driver
- Precise positioning of the jobs
- Transferring the jobs to the engraver
- Visualizing responses from the engraver
- Acquiring job and engraver data
- Controlling the engraver parameters
- Managing the material templates
- Archiving engraving jobs


This is Trotec JobControl® in **Basic** view Version:



This is Trotec JobControl® in the **Advanced** view Version:




This is Trotec JobControl® in **Expert** view Version:





## 4.2 Laser Control Functions

### Engraver Control for Basic & Advanced



### Engraver Control for Expert





#### 4.3 Job Preview

This feature is supported by the Basic, Advanced and Expert View of JobControl®.

The image shows the 'Jobs' window of the Trotec JobControl software. It displays a list of seven demo jobs:

Jobname	R...
Demo Tile Tower	500
Demo Steel Trotec	500
Demo Plastic Tag	500
Demo Veneer Deer	500
Demo Reversible Sign	500
Demo Paper Business...	500
Demo Inlay Wood	500


Below the list, there is a filter section: 'Filter: Standard, 500 dpi' and a link 'Show all'. A duration indicator shows '<104:42' with a clock icon. A checked checkbox 'Job preview' is followed by a preview image of a red decorative tile pattern. At the bottom are standard control buttons: play, stop, and exhaust fan, along with 'Ready' and 'Filter' status indicators.

Checkbox and frame for showing a small picture of the above or on plate selected job.


#### 4.4 Drag snap lines

This Feature exists for Expert View only.


To create a snap line click with the left mouse button on one of the plate rulers (x or y) and hold the click and drag the line over the plate. Drag once positioned snap lines by moving the mouse pointer across the snap line.



Configure snap lines (for Expert): To delete or configure snap line double-click on snap line Rectangle within red circle




Now you can move or delete the snap line




#### 4.5 Side Bar

On the left side of the plate you can dock the side bar which shows tabs for various job information like properties, vectors or process time calculation:



The three tabulators side by side:



## 4.6 File



**New** Ctrl+N  (for Basic, Advanced, Expert): Creating a new material plate.

**Open** Ctrl+O  (for Advanced, Expert): Opening saved material plate.

**Close** (for Basic, Advanced, Expert): Close the current plate.

**Save** Ctrl+S  (for Advanced, Expert): Save the current plate with all jobs.

**Save as** (for Advanced, Expert): Save the plate with a new name.

**Print** Ctrl+P  (for Expert): Printing plate Proof reading.

**Print Preview** (for Expert): Print Preview for printing.

**Print Setup** (for Expert): Setting up the printer.

**Last File** (for Advanced, Expert): Opens the most recently used plate.

**Exit** (for Basic, Advanced, Expert): Exits the Trotec JobControl®.

## 4.7 Edit



**Select All** Ctrl+A for (Basic, Advanced, Expert): Selecting all jobs on the plate.

**Repeat Cut Line** (for Advanced, Expert): Re-cutting of the selected job if the cutting line is not completely sufficient.

**Outline Job(s)** (for Basic, Advanced, Expert): The bounding contour of the job is processed in cutting mode without laser power. The velocity of the outline can be defined in the options menu. Helps to check in advance the correct positioning of materials and/or job(s).

## 4.8 Engraver



**Connect** Ctrl+L (for Basic, Advanced, Expert): Establishes a connection with the engraver attached.

**Disconnect** (for Basic, Advanced, Expert): Cuts established connection with engraver.

**Start** Ctrl+G (for Basic, Advanced, Expert): Starts the engraving or cutting process.

**Pause** Ctrl+F (for Basic, Advanced, Expert): Pauses the engraving process.

**Resume** (for Basic, Advanced, Expert): Continues the interrupted engraving process.

**Stop** Ctrl+E (for Basic, Advanced, Expert):  
Stops the engraving process.

**Normal Performance & High Performance** (for Basic, Advanced, Expert):

This two Options are to adjust the engraving velocity Performance

E.g. Speedy 100: Normal Performance is 180 cm/s, High Performance is 280 cm/s (JobControl® is sold with Normal Performance unless it is ordered with High Performance) and this is valid for all view levels.

**Move Laser** (for Expert): Adjusts the marking head to the position specified

**Move to Marker** (for Expert): Adjusts the marking head to the position of the selected marker. (How to set Marker - see Section 0 - Plate).

**Autofocus** (for Basic, Advanced, Expert): Table moves in focus position to the saved thickness of the currently selected material.

## 4.9 Plate



### 4.9.1 File Format

The current file format has the file name extension \*.pjx.







Plate formats < v6 cannot be opened any more. An error message occurs.




When using a new version of JobControl® for opening an old plate format a warning to check the properties appears.



When using an old version of JobControl® for opening a new plate format a warning to check the properties appears.



If the JobControl® is too old to open the current plate format an error message will appear. This informs the user that he should update the software.



 If pressing **S** or typing Ctrl+S the plate will be stored by using the new file format. The new file extension is simply added to the former file name e.g.: "old.pjf.pjx". Using an old format to save the file is not possible.

#### 4.9.2 Material choice

The material database holds different kind of material groups and named materials.

In the material list you can choose one of the saved materials (see "Define Material Template").

Every job has been printed with an associated material.

If you move a job from the job queue on the plate, the plate obtains its material data from the first job positioned on this plate.

If the job material does not exist it will be pointed out to you that the material data is not matching and the standard material is used.

#### 4.9.3 Material priority

The material selected for the plate always has priority. This means, if you position a job with the material data "Aluminum" on the plate and then select "Plastic" as plate material the job and the plate will be processed with the "Plastic" data.

In addition, you can quickly open a new plate using the Ctrl+N shortcut key.


#### 4.9.4 Plate Setup

 Ctrl+H (for Basic, Advanced, Expert versions)

Defines size and orientation of a material plate.



The Plate Setup dialog is used to customize the plate size, orientation, and material definition for the job being processed.



**Orientation:** Determines the orientation of the plate (Portrait or landscape)

**Engraving Direction:** Defines whether the lines are engraved in horizontal or vertical direction during engraving.

**Job Orientation:** You can select whether the jobs are positioned in portrait or landscape mode. It is advantageous to engrave jobs in the direction of their longest side as the engraving time will be reduced if the engraver has a minimum of interruptions.

**Plates together:** If this option is selected, two plates are positioned side by side and displayed in the JobControl® using a separator.

#### 4.9.5 Job Positioning

**Position Job**  (for Basic, Advanced, Expert): Positions the job(s) marked in the queue on the plate. Select the job you want by clicking once on the job name in the queue. The job is highlighted in color and can now be positioned. It is also possible to position multiple jobs at one time this way.




As an alternative solution to position jobs on the plate, you can double click on the appropriate job name or drag the job onto the plate using the mouse.

**Position Job Multiple**  (for Expert): Multiple positioning of the selected job. This function allows multiple positioning of selected jobs in the queue on the plate up to 100 times.

**Duplicate Job** Ctrl+ D (for Advanced, Expert): Duplicates a marked job in the queue or on the plate.

#### 4.9.6 Ordering of Vectors

**Vector ordering** (for Expert): Re-orders all vectors within a job file to achieve way-optimized processing. This reduced cutting time.



**Quick ordering** is a very fast and easy to use method.

Of course more complex jobs, with a higher number of vectors may require the enhanced ordering method. But bear in mind that the enhanced method is more time consuming.

**Enhanced ordering** takes two parameters.

Mutation is the number of randomly different copies of the job - each job with another vector order. After creation of n mutations, mutation 1 is compared with mutation 2 ... n, mutation 2 is compared with mutation 3 ... n, and so on.

The most optimized mutations are used to create n new mutations. This is repeated for the number of Passes.

**Vector ordering** is only functional when the number of vectors is in the range from 3 to 5000.

**Inner geometries first** → chapter 2.2.5

The cancel button takes only effect between the mutations, before starting a new pass! That's why it does not always react immediately.

#### 4.9.7 Jobs

**Rotate Job** Ctrl + Space  (for Expert): Rotate positioned jobs via the context menu or use the toolbar button. Rotation is always 90° (-90° if applied to already rotated jobs).



**Remove Job**  (for Basic, Advanced, Expert): Puts the job back in the queue.

Click on the job you want to select and remove it from the plate

**Job Reset** Ctrl+ R  (for Advanced, Expert): Resets the job properties

Is required to engrave jobs being already completely processed again, Select the job processed on the plate and then execute "Job Reset".



**Delete Job** Del  (for Basic, Advanced, Expert): Deletes the selected job(s) in all files. This allows you to delete jobs regardless of whether they have already been processed or not. Click on the job on the plate or in the queue and then on "Delete Job".

#### 4.9.8 Marker

**Add Marker to Plate** (for Expert): Sets a marker on the specified position.

Markers are displayed as blue crosses on the plate (selected markers are green). Markers are used as positioning aids for jobs. They have magnetic properties in that they are attracted to the corners or the center of the job. The snap feature can be ignored with pressed ALT Key during Job Repositioning with the Mouse.

**Delete Marker** Ctrl+Del (for Expert): Deletes the selected marker.



**Job to Marker**  (for Expert): Moves selected job to the selected marker



**Marker to Job**  (for Expert): Sets a marker on the position of the selected job or moves a selected marker to the position of the selected job

**Marker to Laser** F8 (for Expert): Sets a marker on the current laser position

**Engrave Intermediate** (for Expert): Is used to fit in urgent jobs while a process is in progress. The urgent job must be manually positioned and marked before the "Engrave Intermediate" function can be selected. The laser then completes processing the data already in the memory, which may take some seconds. The new job will then be engraved and cut if required.

This allows engravings during processing a whole plate.

### 4.10 Settings



#### 4.10.1 Templates



**Material Template Setup** Ctrl+M

Creating, changing and deleting of material templates.

See chapter Material Database for Details

### Size Template Setup **Ctrl+W**

(for Basic, Advanced, Expert)

Name	Width	Height
A2 landscape	594.00	420.00
A3 landscape	420.00	297.00
A3 portrait	297.00	420.00
A4 landscape	297.00	210.00
A4 portrait	210.00	297.00
A5 landscape	210.00	148.00
A5 portrait	148.00	210.00
classic line P01	50.00	30.00
classic line P02	51.00	38.00
classic line P03	54.00	24.00
classic line P04	54.00	30.00
classic line P05	54.00	34.00
classic line P06	60.00	35.00
classic line P07	60.00	40.00
classic line P08	64.00	45.00

New Delete

OK

Cancel

#### Creating, changing and deleting of size templates

Click on a template in the list to select. Settings such as Name and Dimensions may then be changed and saved by clicking on the "OK" button.

To create a new size, click on the "New" button, make the settings, and then save them.

Click on the "OK" button to have the new settings take effect. Click on "Cancel" to undo unwanted changes.



The Define Size Template dialog allows saving of frequently recurring sizes in order to retrieve these from the printer driver.

#### 4.10.2 Options

Information about the options can be found in the section "

Options Dialog".

#### 4.10.3 Create Service File


Creates information file (.TSI) of the laser software

In the case of unexpected software problems, this function is used to create a file which allows analyses performed by Trotec Technical Support. This file contains: Material and size templates, laser settings, positioned engraving jobs, and the Trotec software as well as operating system version number. Graphics data may also be included.

**Functionality:**


Position the job(s) causing problems on the plate.

Open Create Service File dialog.



Select path for the service file and click on Save.

If required, you may then attach a graphics file or any other related file.



Select the graphics file used for creating the job and click on Open. Click on Cancel if you do not want to attach a graphics file.

The service file will then be automatically saved in the previously selected path. This file (ServiceLog.txt) should be sent by email or on a disk to Technical Support together with a description of the problem.

#### 4.10.4 Information


Shows travel and operating time of the laser as well as engraver model and engraver software version.

In order to retrieve this information, the connection to the engraver must be established.

#### 4.10.5 Update Firmware

You are prompted to specify the storage location of the Trotec update file (.TUZ). Then the settings are changed on the laser engraver itself.

Updating of the engraver software is not permitted unless you are instructed to do so by the Trotec Technical Support.



Choose Firmware File.

Connect to Engraver (machine has to be started with open top cover, or referencing has been finished)

Press Send to process Firmware Update.



**NEVER ABORT FIRMWARE UPDATE!**


Restart the engraver after firmware update has been finished.

## 4.11 Options Dialog



for Basic, Advanced, Expert: Set the default values and functions for the laser machine.

### 4.11.1 General



**Language:** Defines the user interface language of the printer driver and JobControl®

**Unit:** Indicates whether millimeter [mm] or inches [in] as default

**Activate JobControl® when new jobs arrive:** JobControl® starts when the Printer driver prints a Job.

**Ignore unsaved documents when closing JobControl®:** JobControl® can be closed without advice to save unsaved documents.

**Apply antialiasing to preview images:** with enabling this option the preview image quality is increased.

**Do not ask if a file with the same name already exists in the recycle bin:** JobControl® will not ask if a job with the same name is deleted which already existed in the recycle bin.


**Spool path:** Path where jobs are placed from printer driver and loaded from JobControl®

**Com-Port:** Manual choice: manually select com port for engraver connection (COM1, COM2...)


**Automatic scan:** detect COM port automatically (default)

## General – Sounds

User defined sounds inform whenever either „engraving finished“ or „machine error“ occurs. This is additional user information in case the PC is located in another room as the engraver. A sound card is required to use this feature.




## General – Warnings



Ignored warnings are listed here.

## General – Remote Control



**Allow Remote connections with JobControl®:** iPhone app remote access to JobControl® is allowed.

**IP address:** IP address of the JobControl® PC.


**Port:** Port for connection to app (system administrator recommended)

**Device name:** detection name of the machine. Maybe important if iPhone app is connected to more than one JobControl® computers.

**Coupling code:** this code is necessary for the pairing of JobControl® and the iPhone app.

## 4.11.2 Hardware

### Hardware – Engraver



**Engraver Model:** Defines the type of laser engraver used.



This information must correspond with the machine actually used. Changing the engraver model can result in faulty machine settings, bad engraving results or even machine damages!

**Max. Velocity:** Indicates the maximum engraving and cutting speed possible. (Information field only, no changes possible)


**Standby Mode:** Switches the laser machine into standby mode after a defined period. Saves energy costs.

#### Tandem Operation:



Since the large format plotters like SP2000 and SP3000 were built without lid it is possible to recharge the machine while it is working which enables the tandem operation with two zones. This makes the machine more flexible and productive.


To activate the tandem operation a secure zone has to be configured by entering the parking position and the bumper width between zone 1 and zone 2. The park position and the double bumper width are defining the area in which no jobs can be placed. This area is shaded red on the plate inside JobControl®.



If one zone is active and the other gets activated the laser will go to the activated zone after engraving is finished. Otherwise the laser will move into park zone if there is no more active zone.

The switch to activate a zone is an extern device that has to be ordered by the local Trotec laser dealer.

## Hardware – Exhaust




**Time to hold:** Defines the period how long the exhaust shall continue working after a job has been completed.

**Start-up time:** Allows the exhaust to start prior to processing jobs

**Suppress warnings:** Exhaust responses will not be displayed (used for Exhausts not originating from Trotec).

## Hardware – Accessories



**Rotary Attachment:** Activate or deactivate the option

**Diameter:** Specifies the diameter of the work piece

**Rotation speed:** Which portion of full speed is used for connection moves.

**Rotary homing:** Homing move configuration for rotary.

- **move to 0° on begin and end:** rotary moves to 0° before and after job has been finished
- **no moves:** rotary doesn't move after job has been finished
- **return to start position:** rotary moves to start position (position before job start) after job has been finished




This page will be automatically completed when positioning a job that has been printed using the "Rotary Attachment" option. However settings can be adjusted here. Changes are only possible when no job is positioned on the plate.

**Camera option:** Signals JobControl® that an i-cut camera is attached. The plate size in JobControl® is reduced with the defined Margin values. X and Y Moves are limited in firmware automatically to avoid crashes.


**Honeycomb table:** Activate or deactivate the option.


**Thickness:** Specifies the thickness of the honeycomb table. This value is used for calculation of the software focus. Wrong values can lead to head crashes.

**Table options for Speedy 360:** For this plotter machines there are some more options regarding the tables to pick.



When using Version 1 you can only choose the standard table but with Version 2 you can choose from a list:








When tickling "use honeycomb" is enabled you can then add thickness to the table.

**Table options for Speedy 500:** For this plotter machines there are some other options regarding the tables to pick.

#### Settings for Version 1:



#### Settings for Version 2:

Table options SP500

Version 1       Version 2

<input checked="" type="radio"/> Vacuum table	3.00
<input type="radio"/> Cutting table	0.00 mm
<input type="radio"/> Cutting grid table	21.00 mm
<input type="radio"/> Vacuum table + tabletop	3.00 + 24.00 mm




Table options SP500

Version 1       Version 2

<input type="radio"/> Vacuum table	3.00
<input checked="" type="radio"/> Cutting table	0.00 mm
<input type="radio"/> Cutting grid table	21.00 mm
<input type="radio"/> Vacuum table + tabletop	3.00 + 24.00 mm




Table options SP500

Version 1       Version 2


<input type="radio"/> Vacuum table	3.00
<input type="radio"/> Cutting table	0.00 mm
<input checked="" type="radio"/> Cutting grid table	21.00 mm
<input type="radio"/> Vacuum table + tabletop	3.00 + 24.00 mm



Table options SP500

Version 1       Version 2

<input type="radio"/> Vacuum table	3.00
<input type="radio"/> Cutting table	0.00 mm
<input type="radio"/> Cutting grid table	21.00 mm
<input checked="" type="radio"/> Vacuum table + tabletop	3.00 + 24.00 mm






## **Hardware – Vision**

Please refer to the chapter 5.JobControl® Vision

#### 4.11.3 Process options



**Lens selection:** Shows current lens selection

**Outline Velocity:** Defines velocity in percent of maximum engraving velocity for the outline functionality.

**Laser homing:** Defines the laser position before and after job execution (not for rotary jobs)

- **move to (0,0) on begin and end:** laser head moves in the top left position (0,0) before and after job has been finished
- **no moves:** laser head doesn't move after job has been finished
- **return to start position:** laser head moves to start position (position before job start) after job has been finished

**Autofocus at start:** If activated a software autofocus is executed before job start.




Lens type, material thickness and table (cutting table...) have to be adjusted correctly to avoid head crash.


Never put any parts of your body inside the engraver while the table is moving!

## Process options for SP2000 and SP3000

Additional functionality for SP2000 and SP3000 is the safety position in Z.



The following options can be chosen from the list:



The greatest value for the safety distance is 50 mm.

Safe distance in Z      50.000 mm

If the safety position is activated "at start and end", then the head will move up before moving towards the first work piece, moves down into focus position during work and will move up again as soon as all work pieces are finished. Typically this option is used together with laser homing to avoid crashes with tilted materials.


If "between jobs" is activated, the head also moves into safety position if the engraver changes the processed job.




Safety position and autofocus at start cannot be used at once. If safety position is activated the autofocus at start is automatically deactivated.  
Beware: The focus position is lost after JobControl® is closed!

To get control over focus position and z axis use the toolbar described in this chapter: Safe Position

## Process options – Stamp



**Shoulders:** All shoulders are listed by their name and can be added, removed or edited:




**Cut Border:** Distance between cutting line and neighboring job

These settings are required for stamps and should only be changed after consulting Trotec Technical Support.




## Process options – MCO (Multi Color Option)



**Auto create stamps:** Automatically create stamps when MCO jobs are processed

- **Power, speed, frequency, correction:** Laser settings for cutting pads of MCO jobs
- **Dye duration:** The time each MCO color is inked
- **Used MCO colors:** Configuration whether inking is active and which MCO colors are used

### User defined MCO colors:



User can add, modify and delete his own MCO colors.


**Version:** Version of all MCO user colors / MCO user colors file

**Name:** Name of MCO color

**Id:** Id of MCO colors (usually "Red|Green|Blue" value)

**Level:** Field for future use

**Color:**



Shows assigned RGB color

**Choose:** Shows RGB color configuration dialog


**Type:** Field for future use

**Replaced by:** Shows MCO color which replaced this one

**Correction Target:** Whether this MCO color can be corrected to at time of MCO processing

**Dye duration:** Time how long one dye point is inked

## Process options – Link



Links are controlled cut-line interruptions. They are used to hold e.g. stamp dies in the sheet material. That way the entire rubber sheet can be removed conveniently after processing. The distance from one link to another, the link width and the percentage of currently adjusted laser power can be modified.

### Use links:


- never: don't use links with
- stamps only: use links only for stamp cutting processes (recommended)
- always: use links for all cutting processes
- once only: use links for the next job, then link configuration is changed to never

**Link distance:** distance between links

**Link width:** link width

**Power ratio:** power ratio in percent of max power

## Process options – Automation



The following settings influence the automation feature which can be started within right mouse click menu in job queue.

**Position first job:** Define automation job position


**Use second job/Position second job:** Defines second automation job position

**Auto toggle (continuous processing):** This feature toggles between first and second automation position without pause.


**Conveyor belt:** This feature needs integration of conveyor belt into engraver.

## Start Job Automation

Empty the JobControl® plate, and then open the context menu of the job in the job queue




Click on Job Automation




Enter how often the job should be processed

## Process options – QuickPrint



X, Y: Point where QuickPrint-Jobs are placed and processed

## Process options - Layer




**Number of Layers:** Specifies the number of layers the engraving should be carried out in. The layers are engraved alternating once in X and once in Y direction.

**Z-adjust for each layer:** z-adjust between the layers for re-focusing.

#### 4.11.4 Service

Settings for service personnel only!

##### Service – Laser




All laser parameters may only be changed after consulting Trotec Technical Support staff!

**Power Test Pulse (only CO<sub>2</sub> systems):** Sets the test pulse power, only required during service!! If this value is set to 100%, it is the instantaneous power; otherwise the laser power increases continuously.

**Laser Warm-Up:** Automatic laser warm up for CO<sub>2</sub> systems. This setting helps the laser source to work properly after a longer period of inactivity

## Service – Service settings – Laser settings



**Tickle delay (only CO2 laser systems):** Should be increased if the stamp appears blurred.

**Tickle Power (only CO2 laser systems):** Power required to excite the laser tube and put it into standby mode


**Update:** Writes the changed values to the engraver's memory

**Diode Current YAG:** (only YAG/fiber laser systems) Threshold current of the laser.

**Focus difference YAG-CO2:** Only for hybrid systems

**Automatic focus mode:** The Speedy 360 is shipped with either Light bar focus or Sonar Technology™. SP2000 and SP3000 are shipped with Sonar Technology™. Some engraver systems do not have a machine focus.

## Service – Service settings – Correction




**Acceleration, K1, K2, K3:** Values which influence graving quality

**Laser interlock delay time:** Time the laser becomes active after the lid was closed. Settings below 5000 ms require a special hardware extension.

**Velocity controlled connected moves:** Enable/disable velocity control in firmware.

The function "velocity controlled connected moves" is removed from option dialog as soon as there is a path planning in use. Then the path planning is taking care of the acceleration along the path.

## Service – Service settings – Offset



### Group Axis

**X-Axis offset, Y-Axis offset, Z-Axis offset:** Offset values which modify shown X, Y and Z values.

**Get Current Position(s):** Use current position of laser or table as offsets.

### Group Lens

**Lens type:** For each lens type an offset value can be entered. This will make automatic focus mode more accurate for each lens.


**Default:** The calculated difference between default lens (which is used to adjust the Z-Axis Offset) and chosen lens.

**Corrected:** The measured difference between default lens and chosen lens.


**Get Current Position:** Use current position of laser or table as offsets.

The group "Lens" is only shown if an engraver is chosen that has a table that can move in z-axis. It is not shown if the offset can be changed inside the laser head.

## Service – Service settings – Overtook




Show and edit correction values for overtak

**Service – Service settings – Acceleration**

X, Y, Vector and Circle values for acceleration. Click “Reset” to restore Default Acceleration settings for engraver.


If the chosen engraver supports path planning, this page is not shown since the path planning parameter are taking care of acceleration.

## Service – Service settings – MCO parameters




The MCO dialog is only shown if the chosen engraver supports the multi color option.

## Service – Resolution




The Resolution Tuner can be used to change the resolution inside JobControl® and the Trotec laser that is operated by JobControl®.



As soon as the Resolution Tuner connects with the engraver the connection of JobControl® will close. The resolution can be changed by sliding the control. This can also be done by using the arrow keys, the step size will be hundredth percent. The change in the resolution is shown in the field for x and y resolution. The unit is nanometer.

If the JobControl® or the firmware is updated the changed resolution is lost. Therefore the resolution tuner needs to be opened again and the stored values must be sent to the laser.

## 4.12 View




### 4.12.1 Status Bar

General information such as the preset material of the active plate is displayed in the status bar.


### 4.12.2 Toolbar JobControl® - Advanced

The toolbar provides quick access to commonly used functions.



#### 4.12.3 Toolbar JobControl® - Expert

The toolbar provides quick access to commonly used functions.




#### 4.12.4 Zoom

For Advanced and Expert.

The zoom bar enables you to display the plate at the magnification you want. You can use the scroll bars to the right of and beneath the plate to navigate within a magnified plate.

The function keys F3 and F4 provide quick access to Zoom Out and Zoom In.




#### 4.12.5 Job Position

For Advanced and Expert.

The job position bar provides information on the X and Y position of a marked job on the plate. Precise job positioning is possible by manual entry of the required coordinates.

Depending on reference selected, the coordinates are either displayed in one of the corners or center of a job.





#### 4.12.6 Material Parameter

For Expert.

The material parameter bar displays the main properties of the currently active material. All parameters may be changed. You can undo or save changes using the two buttons on the right.

Changes to power, speed, and PPI/Hz will have an effect on processes being currently in progress with a slight time delay. It is necessary to confirm the change to the value by using the Tab or Return key.



Should be entered correct as soon as a material has been changed. The software autofocus is calculated with this value!


#### 4.12.7 Laser Position

For Expert.

Display of the X, Y and Z axis position.

The Move X/Y/Z button allows moving to any entered absolute position.

Focus Laser moves the table to the focal point, with consideration to material thickness, lens and honeycomb table.




Never press any move-button or Focus Laser button while someone's bodily parts are inside the engraver!

Never put any bodily parts inside the engraver while the table is moving!

#### 4.12.8 Lens Toolbar

For Expert.

The lens that is used should be entered here. Some offsets might be used by lens.




The amount of lenses shown here is dependent of the engraver in use.

#### 4.12.9 Software Autofocus Toolbar

For Expert.

The tool bar for the software autofocus includes

- The button to activate software autofocus at job start
- The button for software autofocus




When using software autofocus be aware to have your material thickness up to date. Otherwise the software autofocus may lead to a head crash!


#### 4.12.10 Safe Position

For Expert but only for SP2000 and SP3000.

The big plotters have the safe position as an option available. If the option was not activated inside option dialog, then the toolbar looks as in the next picture. The buttons and the text field are greyed out. The toolbar can be viewed but not used.



After activating safety position in z inside process options the toolbar will be activated.



When the toolbar is activated the button can be clicked after the machine entered focus position to store the value and move into safe position immediately.

Alternately the job can be started with the start button, the current value of Z will be stored inside the toolbar, the laser head moves up in safety position and the head moves to the position of the first job.



In this condition the position of the laser in the z axis cannot be changed manually. Only when activating the machine autofocus it is possible to move the laser in Z.

Depending on the chosen option the laser head will move into safety position during fast moves. This are the moves from start position to the job, between jobs and at the end from job to start position or reference position. Only if the laser has work to do the head should move down into focus position.

More information about the options of safe position can be found in this chapter: Process options

#### 4.12.11 Job Queue

The Job queue displays all jobs which are printed but not positioned on the plate. They are listed in alphabetical order optionally by any columns.

Jobname	Resolution	Date
Demo Plastic Tag	500	10/4/2016
Demo Paper Business Card	500	10/4/2016
Demo Veneer Deer	500	10/4/2016
Demo Reversible Sign	500	10/4/2016
Demo Inlay Wood	500	10/4/2016
Demo Tile Tower	500	10/4/2016
Demo Brass Trophy Plate	500	10/4/2016
Demo Wood Cut	500	10/4/2016
Demo Steel Trotec	500	10/4/2016

Duration: <5:41

You can sort every column with click on the column name. To sort all jobs with their Job name click on Job name with the mouse.

It is possible to modify the columns of the job queue with right mouse button click.

I...	Jobname	Resolution	Date
<input checked="" type="checkbox"/>	Icon		/2016
<input checked="" type="checkbox"/>	Jobname		/2016
<input checked="" type="checkbox"/>	Resolution		/2016
<input checked="" type="checkbox"/>	Date		/2016
	Date, Time		/2016
	Process		/2016
	Filename		/2016
	Material group		/2016
	Material name		/2016

Duration: <5:41

##### Icon

Shows the icon of the Job process.

##### Job name

Shows the job name of the print job. Job name has been defined with printing process.

### Resolution

Shows the printing resolution in Dots-per-Inch (DPI). Resolution is defined with printing process.

- ✓ Date: Date format: system region settings dependent (e.g.: mm/dd/yyyy)
- ✓ Date, Time: Date format: system region settings dependent (e.g.: mm/dd/yyyy hh:mm)
- ✓ Process: Standard, Stamp, Layer, Relief, Photo optimized...
- ✓ Filename: \*.tsf filename of printing job

You can move the columns to different position with drag and drop.


Jobname	Resolution	Date
 Demo Plastic Tag	500	10/4/2016
 Demo Paper Business Card	500	10/4/2016
 Demo Veneer Deer	500	10/4/2016
 Demo Reversible Sign	500	10/4/2016
 Demo Inlay Wood	500	10/4/2016
 Demo Tile Tower	500	10/4/2016
 Demo Brass Trophy Plate	500	10/4/2016
 Demo Wood Cut	500	10/4/2016
 Demo Steel Trotec	500	10/4/2016

Duration: <5:41




If a job from the job queue is positioned on the plate, the Filter settings are set to the Resolution of the positioned job.

**Export Jobs:** Export jobs from within the job queue or plate, by using the context menu. Exported jobs are stored in compressed format (ZIP).



#### 4.12.12 Engrave Time Calculation


For Expert.



Duration calculation estimates the process time of the selected Job in the queue or on the plate. The estimated time is an indication for the process time but must not meet the real process time. To get an improved process time forecast open the calculation sidebar and click on Update.


## Calculation Sidebar

For improved calculation please open the calculation side bar and click on update. This calculation can take a while if the job is very complex.




#### 4.12.13 Properties

Opens the Job Properties Sidebar which shows import info about the selected job on the job queue or plate. The properties include order name, order number, file name, and processing parameters.



#### 4.12.14 Vectors

Shows all vectors in the job.



#### 4.12.15 Job History

For Advanced and Expert.

ID-Number	Date	Start	Duration	Jobname	Jobnumber	Filename	Kind	dpi	Power
1	2012-10-22	16-15	00-00-18	blah	64	blah.tsf	Standard	500	50.00
2	2012-10-22	16-16	00-00-20	blah	64	blah.tsf	Standard	500	52.00
3	2012-10-22	16-16	00-00-17	blah	64	blah.tsf	Standard	500	52.00
4	2012-10-23	09-52	00-00-23	5206Segment.cdr	2220	1-14480265-1-240694	MCI Pad	500	50.00

Print    Export...    display entries from:  to:     OK

List of all jobs processed with date, processing time, job name, job number, filename, kind, dpi and power. The user may use the list to create statistics or for calculations.

An inbuilt export function creates a file, if required, which can be opened and edited with Microsoft Excel® for example.

#### 4.12.16 Recycle Bin

Job	Deleted at
Graphic1 0001.tsf	17.10.12 08:51:54
Graphic1 0002.tsf	17.10.12 08:53:49
Graphic1 0003.tsf	17.10.12 08:54:04
test_1.tsf	19.10.12 13:08:59

[Undelete](#)    [Close](#)

Dialog for showing and undeleting already deleted jobs



---

**4.12.17 WYSIWYG on/off**

For Advanced and Expert.

If WYSIWYG is activated all jobs on the plate will be displayed with their graphic contents. This makes positioning easier and helps searching for jobs.

Cutting lines are only displayed if the appropriate color is activated for cutting. This is also used to check if unwanted cutting lines may exist.



With less powerful computers or the display of large complex graphics, image formation may take some seconds. In these cases, it may be useful to deactivate the WYSIWYG function to ensure fast processing.

## 4.13 Window

**New Window**

Opens a new window for the current document.

**Cascade**

Arranges the windows so they overlap.

**Tile**

Displays the windows side by side.

## 4.14 Help

**Help F1**

Opens software manual (PDF Reader has to be installed).

**Laser Manual**

This option opens the Operation Manual for the engraver (PDF Reader has to be installed).

**What's New?**

Shows JobControl® Release Note (PDF Reader has to be installed)

**User Registration**

Register your JobControl®

**Software Registration**

This option allows updating the software to different view levels and options.

**Trotec on the web**

Displays the link to Trotec web ([www.troteclaser.com](http://www.troteclaser.com)).

**About JobControl®**

Displays program information, Version number and copyright.

#### 4.15 List of available shortcuts

Function Key	Description
F1	Help
Ctrl + -	Zoom Out
Ctrl + +	Zoom In
Ctrl + 0	Zoom to Plate
Shift + F4	
Alt + 0	Zoom to Jobs
F4	
F8	Marker to Laser
Ctrl + N	New Plate
Ctrl + O	Open Plate
Ctrl + S	Save Plate
Ctrl + P	Print
Ctrl + A	Select all Jobs on Plate
Ctrl + R	Reset selected Jobs
Ctrl + G	Start
F12	Start
Ctrl + F	Pause
Ctrl + E	Stop
Ctrl + H	Plate Setup
Ctrl + D	Duplicate Job (either on plate or in job queue)
Del	Delete Selected Job(s)
Ctrl + Del	Delete Selected Marker
Ctrl + M	Material Template Setup
Ctrl + W	Size Template Setup
← (backspace)	Put Job back in Queue
Ctrl + Space	Rotate Job
Ctrl + L	Connect to Laser



Ctrl + J

Options

## 5 JobControl® Vision

### 5.1 Overview

JobControl® Vision Software: precise laser finishing of printed materials.

Create Print&Cut acrylics, paper, film or cardboard products.

The Vision module uses registration marks to determine the position and rotation of printed sheet material on the working area of the laser.

Additionally, the intelligent JobControl® Vision camera recognizes any distortions - linear or non -linear - in the printed graphics.

By applying sophisticated mathematical algorithms the system compensates for the detected print distortions and adjusts the cutting path dynamically to match the artwork. No matter if flexible or rigid materials.

How it works in simple words: The registration marks are printed along the image. The camera - which is attached to the working head - "reads" the registration marks prior to the cutting process and compares the "read" positions on the printed design and the target positions in the original cut file.

Any deviations are adjusted automatically. There is no need for manual alignment which speeds up your production and costly miscuts can be avoided. This guarantees a perfectly cut end product.

Create amazing details and meet tightest tolerances - with Trotec JobControl® Vision.

## 5.2 Hardware Guide

### 5.2.1 Vision Camera

JobControl® Vision System uses a high quality USB camera device with special plug system which allows removing of camera without any loss of time.



JobControl® Vision Camera system with LED/protection adapter.

## 5.2.2 Camera Connection

Before starting the JobControl® ensure that the USB repeater is connected on the backside of the laser machine and onto an USB slot of the PC. This connects the camera inside the laser machine with the computer. JobControl® Vision will not find the camera if the cable is attached while JobControl® is already running.



If the connection of JobControl® Vision with the camera fails, first ensure that the camera is connected to the PC with USB repeater successfully. Connecting to another USB hub might help solve the problem. Restart JobControl® after changing something on the cable connection.

### 5.2.3 Camera LED adapter

The JobControl® Vision System is delivered with a LED adapter for camera illumination.



Be aware that laser processing with camera without LED adapter can contaminate camera optics.

The LED adapter can be attached with plug system without any screws.



## Cleaning of LED adapter



LED adapter needs to be clean because contamination can negatively influence the camera detection. The acrylic glass of the LED adapter can be cleaned with window cleaner but avoid aggressive materials like acetone because of blurring.

#### 5.2.4 Removing of the camera

To remove the camera first open the 2 fixing screws and then pull the camera out of the plug system.



### 5.2.5 Camera Sharpness Adjustment

The camera sharpness is preadjusted for laser delivery configuration so it's no demand to change this setting in general.

But it may be possible that special applications or different laser lenses need different camera sharpness. So this can be adjusted easily.



The adjustment is typically done with attached camera and with JobControl® Vision camera view. The laser is focused on the work piece and the camera view should show a work piece regmark.

First untighten the black fixing wheel of the optic and then turn the optics until the work piece regmark is perfectly sharp.

Tighten the fixing wheel to preserve the sharpness settings of the camera.

If laser processing with camera but without LED adapter occurs it's highly recommended to check camera optics for contamination.

To remove camera optics contamination please clean the camera lens with laser lens cleaner carefully.

### 5.3 Supported Applications

As for now the applications listed below are capable of sending regmarks to JobControl® Vision.

- ✓ CorelDraw
- ✓ Adobe Illustrator
- ✓ Inkscape
- ✓ Pdf Reader (please notice that Pdf files must contain Bezier path in order to send regmarks to JobControl® Vision)

Applications which are not able to send regmarks to JobControl® Vision

- ✓ ACad
- ✓ SolidWorks


## 5.4 Workflow How-to

This how-to shows you how to create a basic Print&Cut application in Corel Draw and to cut it out with JobControl® Vision.

The JobControl® Vision workflow can be applied for Adobe Illustrator with some minor changes.

### Preconfiguration of CorelDraw

The printing application (e.g. Adobe Illustrator or CorelDraw) needs to support Bezier output which has to be activated for the Trotec printer driver



### Set up artwork

Open Corel Draw and open a new page with A4 sheet size.

Create your artwork. In this case we use a part of the Trotec logo.




Figure: Create artwork in Corel

Add a cut line to your artwork. Use one of the 16 RGB colors from the Trotec color palette with line width "Hairline" for your cut line. In our case we use red.



To make color mapping easier the Trotec color palette can be imported from the JobControl® installation DVD.




Fig. : Import Trotec color palette from JobControl® installation DVD into Corel Draw

Add 3 registration marks in the outer corners of the A4 sheet. It's recommended to use 6 mm as reg-mark diameter. Apply a black outline with line width "hairline" and a black fill.




Figure: Artwork, cut line and regmarks on one page

This is our print and laser ready job.



It's recommended to put regmarks, artwork and cut lines on separate layers.  
By doing this you can easily enable and disable layers for printing.




Figure: Artwork, cut line and regmarks on different layers

### Prepare and print artwork job to printer

Print the artwork and regmarks on the work piece.



The job cut lines would interfere with the artwork print so they should not be printed. With dedicated layers it's straightforward to disable the cutline layer for printing. Without layers just delete the cut line and undo delete after you have printed your job.

Now export a pdf and send it to the printer or directly print from your Corel.




Figure: Exported PDF is ready to print

#### Prepare and print cutline job to printer

Print the regmarks and cut lines to the laser.



The artwork layer should be disabled for this print.

Now go print. Select Trotec Engraver Printer Driver and open "Preferences" dialog.




Figure: Print window in Corel Draw

Set page size to A4 format. And open material database by clicking the highlighted button.




Figure: Trotec printer driver preferences window in Corel Draw

Select material group "Paper" and create a new material "Paper Print&Cut". For color red select process type cut. Add and adjust your laser parameter for your red cutline. In our case we use a Speedy 400 80 watts and a 1.5" lens. We use 60% power, 1% speed, 1000 Hz frequency and air assist on.




Figure: Trotec material database

For color black select process type regmark. By doing this JobControl® now knows that the black objects are regmarks and the laser job is a vision job.




Figure: Select process type "RegMark"

Click the OK then the JC button and you will exit the preferences window.

Click print and the job will be print to the JobControl® job queue.

### Checklist for successful printing of regmark jobs

- ✓ Bezier curves output has to be activated in graphics software.
- ✓ Regmarks have to be defined with circle contours.
- ✓ Supported regmark size: 2 - 12 mm
- ✓ The contour of the circle needs to be active
- ✓ Contour color in the material database has to match the contour color of the regmark.
- ✓ Regmark color has to be defined in material database before printing.
- ✓ Contour width needs to be as small as possible (hairline)
- ✓ The circle needs to be perfect – ellipses are ignored.
- ✓ It's recommended to print the job with 1000 DPI. This improves the accuracy significantly without loss of productivity.

### Prepare Laser and JobControl®



Ensure that USB camera is connected to the PC before JobControl® start.  
If camera is not attached to the PC and JobControl® has already been started please close JobControl®, connect the USB camera and restart JobControl®.

Connect to the laser.

Take your printed A4 sheet out of your printer and put it on the working area of your Trotec laser. Use a black aluminum cutting grid table or a vacuum table with honeycomb. Check lens for cleanliness and focus on the material.

### Prepare JobControl®

Put your laser job form the queue on the working area. Position it on the working area either at 0/0 or to the position where you printed A4 sheet is in the machine.




Figure: Laser job on working area of JobControl®

Now you are ready to cut the job.

### Process the cutting job

Click play.

The JobControl® Vision run screen opens.

If the JobControl® didn't appear and the cutting of the job starts immediately instead please abort the job and check material settings for correct regmark color process enabled.



If there is a good match between job position and work piece JobControl® can find all regmarks automatically. To ensure that this is possible move the laser pointer of the laser to the center of a regmark on the work piece. Then move the Job on the JobControl® Plate so that corresponding regmark positions match.




Figure: Work piece regmark matches the corresponding regmark on the plate

If the position does not match you have to interact with the system and teach the system the first regmark position.

In this case JobControl® Vision will indicate the position of the first regmark.

You have to navigate the camera over the first regmark by using the keypad on the laser, the software arrow keys or the arrow keys on the computer keyboard.

When the camera center is centered over the first regmark and the system has recognized the regmark successfully the regmark is highlighted with a green circle in the camera window. Then press enter.




Figure: Camera detects regmark and is ready to proceed

Now the system travels to the second regmark.

If the work piece is not rotated and without heavy distortion the regmark and all other regmarks are read automatically.

If the alignment was not ok or there were print distortions in the job the position of the second regmark will be off.

You have to teach the system the position of the second regmark. Do the same procedure as at the first regmark.




Figure: Second regmark is indicated because alignment was not correct

After teaching the system the second regmark it will find the third regmark automatically and cut the job.

#### What if my cut does not match my print?

Verify correct compensation strategy. Nonlinear compensation works best in most cases.

Clean camera window and calibrate camera offset. Please see JobControl® documentation for camera offset calibration.

#### What if my regmarks cannot be recognized?

Adjust camera parameters or reset to default parameters.

Exposure: 4, Gamma: 13, Threshold: 24


Clean Camera Window.

Please see JobControl® documentation for camera image adjustment.

#### What if a regmark is damaged and therefore cannot be recognized?


You can manually skip regmarks. This is only possible if you respect the minimum number of regmarks (E. g. if you have 3 regmarks you can skip 2 regmarks - with compensation type position).

## 5.5 Vision Configuration



**Compensation Type:** defines the way the regmarks influence the cutting size, position and distortion.


**Positioning only:**



Compensation: only Positioning, (no Scaling, no Shearing, no Rotation)


Minimum number of Regmarks: 1

**Positioning and Rotation:**




Compensation: Positioning and Rotation (no Scaling, no Shearing)

Minimum number of Regmarks: 2

**Position, Rotation and Scaling:**

Compensation: Positioning and Rotation and Scaling (no Shearing)

Minimum number of Regmarks: 3

**Fully nonlinear:**

Compensation: Nonlinear

Minimum number of Regmarks: 3



**Image Detection:** defines the detection device which is used for regmark detection.

- **Camera:** default setting for JobControl® Vision
- **Laser pointer (demo mode):** Instead of the camera the laser pointer can be used to manually detect regmarks. It's recommended to print small crosses inside or instead of the printed regmarks on the work piece.

**Camera Settings:**

- **Exposure:** defines the amount of light which is used for image detection. With camera light attached this value is generally lower than without.
- **Gamma:** this value influences the illuminance of the camera image.
- **Threshold:** this value is used for regmark detection algorithm to decide whether a regmark is found or not.
- **Advanced...:** load camera configuration file

## 5.6 Camera Offset Calibration



Camera calibration automatically estimates the difference between laser head and camera.

### Camera calibration needs to be done under following circumstances:

#### Common:

- It's recommended to calibrate the camera once a week.
- After first installation of JobControl® Vision
- After the focal point has changed because of one of those reasons:
  - Camera lens has been changed or readjusted.
  - Working defocused without material database defocus feature leads to a different camera lens focal point. In this case the camera calibration needs to be done defocused to or use defocus values in material database.
- Constant discrepancy of cut path in one or two directions has been detected.

#### Rarely:

- After laser beam alignment
- After replacement of camera with different camera

**Insert the calibration material into the machine.**

The material needs to be cut able, mark able or engrave able because the camera needs to recognize the processed circle.

For CO2 Laser machines this is usually a blank piece of paper or anodized aluminum.




Calibration on anodized aluminum has to be done without camera illumination because of back reflection. Exposure: 70, Gamma: 5, Threshold: 220 are verified values for good detection of the cut regmark in this case.

For Fiber Laser machines anodized aluminum can be used too.

**Focus on the calibration material**

Adjust the power and velocity values:


The values P=5 and v = 0.5 may work for a blank piece of paper.

**Press Start Button**

The calibration routine has finished press Save to store the new camera offset settings.


## Common Issues

The cut circle is not detected automatically. Move to the circle manually with software cursor keys or with machine cursor keys.




There is no circle on the material. Repeat the calibration routine with increased power settings or with different material.

There is a circle on the material but the circle is not detected automatically.



Readjust camera with Adjust... Button

Press Ok



Press Ok Button to finish Calibration.

## 6 Graphics Software

### 6.1 Contours and Fills

The Trotec printer driver differentiates between raster mode (engraving) and vector mode (cutting) by the type of the graphics used and the selected process in the used material colors.

For laser cutting, set the line generated in the graphics program to the smallest line width possible.

Assign the color you want to this line – Red is very common – and chose a cutting process for the red color. The printer driver interprets these objects as vectors and cuts them.

If objects are to be cut, always be aware that the driver may interpret a contour which is too thick as fill.

If a thin red line is printed with engraving process for color red the resulting job does not include any vectors because the red lines are half toned and can only be engraved not cut.

If engraved and cut objects are combined, different colors are used for the fills and contours as engraving requires power values different to cutting. Objects to be engraved are therefore usually drawn with a black fill and cutting lines as red contours.

### 6.2 Image Processing Order

When cutting and engraving graphics, the laser carries out all engravings first and then all cuttings. All black filled objects for example are engraved first and then all red contours are cut. Unlike engraving, the cutting is done in the order the contours were drawn. There are two different ways to define the cutting order. You can either draw them exactly in the order they should be cut or you select "Arrange" in the graphics program and place them "behind" the other objects with this function in order to cut the contour you want first. As a third option you can assign different colors from the Trotec material templates to the cutting lines. They will then be cut exactly in the order listed in the templates.

### 6.3 Overlapping Fills

If graphics contain overlapping black filled areas, the driver will automatically filter these so that these overlapping areas will not be engraved twice. The whole filled area of the object lying on top and only the visible part of the object located underneath are engraved. The end result is like a print view.

White can be used as a very helpful drawing tool. As the laser does not engrave white areas (this is the background color), these can be used to block unwanted engraving areas from filled areas or bitmaps.

### 6.4 Overlapping Outlines

The Trotec printer driver does not filter overlapping outlines. If one red outline is placed on top of another, both contours are cut by the laser. This is a helpful function, when thick materials are to be cut. To use this function, double an outline. Another possibility is to set the "Cut ... passes" option in the "Job" tab of the engraver driver to "2". This function can also be set with the "Job Setup" menu command in the Trotec JobControl<sup>®</sup>.

## 6.5 Hidden Vectors in Graphics

The Trotec printer driver does not automatically filter outlines, which are, for example, overlapped by objects such as fills. If hidden red outlines are located under a black filled area, the laser will first engrave the fill and then cut along the hidden outline.

## 6.6 Power Control through Color Selection

The Trotec JobControl® allows the selection of 16 different colors in the material templates to specify 16 different power levels during cutting or engraving. When using this function, the colors in the graphics program must match exactly the colors listed in the Trotec JobControl® (on using Corel draw make sure that color management is „OFF“). In some graphics programs these Basic colors are already predefined, with other programs, you must define each color separately with its RGB components first. If the 16 driver colors are not automatically available in the software, use the values in the following list:

		RGB Color Model			CMYK Color Model			
No	Color	R Red	G Green	B Blue	C Cyan	M Magenta	Y Yellow	K Black
1	Black	0	0	0	0	0	0	100
2	Red	255	0	0	0	100	100	0
3	Blue	0	0	255	100	100	0	0
4	Desert	51	102	153	40	20	0	40
5	Cyan	0	255	255	100	0	0	0
6	Green	0	255	0	100	0	100	0
7	Grass	0	153	51	60	0	40	40
8	Forest	0	102	51	40	0	20	60
9	Olive	153	153	51	0	0	40	40
10	Brown	153	102	51	0	20	40	40
11	Walnut	102	51	0	0	20	40	60
12	Plum	102	0	102	0	40	0	60
13	Purple	153	0	204	20	80	0	20
14	Magen	255	0	255	0	100	0	0
15	Orang	255	102	0	0	60	100	0
16	Yellow	255	255	0	0	0	100	0

## 6.7 Bitmap and Vector Images

A bitmap is a pattern of points that form a picture similar to the ones in newspapers. Bitmaps can be generated by scanning of pictures or by drawing in a bitmap processing program. In the bitmap format thicker lines and surfaces are also represented as individual points. There are two major kinds of bitmaps: monochrome and gray-scale bitmaps. Monochrome bitmaps are 1-bit black-and-white pictures (scanned line drawings), gray-scale bitmaps are 8-bit pictures (scanned photographs).

## 6.8 Scanning of Pictures

When scanning black-and-white pictures, select a high dpi resolution as the pictures turn out sharper. 300 dpi is the recommended minimum resolution to scan line drawings (monochrome bitmaps), but usually 600 dpi provides a much higher image quality. Gray-scale bitmaps should always be scanned at 300 dpi. Scanning with more dpi does not provide better image quality and needs more memory. As a rule-of-thumb photographs should be scanned with 300 dpi and line drawings with 600 dpi. Don't hesitate to experiment with different scan resolutions and note the results.


There are different bitmap data formats as e.g. TIF, BMP or PCX. The format makes no difference to the printer driver. The difference lies in the way bitmaps are stored on the hard disk of your computer.

## 6.9 Image tracing

Most graphics programs cannot edit bitmaps directly. Some Basic functions as zooming in and out or mirroring may be possible, but individual image pixels cannot be altered. For this purpose a special image processing program is required e.g. Photo Shop<sup>®</sup>.

## 6.10 Multicolor Option - MCO2


MCO2 processing now supports more than 4 MCO colors with defining user MCO colors. At the beginning of a MCO graving the nozzle configuration dialog for customizing MCO colors to nozzles is shown:



The checklist box shows all MCO colors for the selected jobs and can be configured via the checkboxes, Up/Down, Insert empty Nozzle/Remove empty Nozzle (for leaving a nozzle without MCO color e.g. nozzle is broken).

"Cut and Ink" cuts all pads firstly and then inks every MCO color. "Only Ink" omits the cutting step.

After every 4 MCO colors a dialog informs you to change the nozzles.



**7 Index**

Admin mode .....	30
<b>Auto Position activation .....</b>	<b>24</b>
Camera .....	92
Camera focus .....	97
Camera light .....	94
Compatibility .....	8
Computer requirements .....	5
<b>Cut job process .....</b>	<b>19</b>
Dpi .....	79
<b>Enhanced geometries .....</b>	<b>22</b>
<b>Exhaust .....</b>	<b>56</b>
<b>File format .....</b>	<b>42</b>
Hz .....	28
<b>Inner geometries first .....</b>	<b>22</b>
JobControl <sup>®</sup> .....	35
JobControl <sup>®</sup> installation .....	5
<b>Language .....</b>	<b>51</b>
Laser power .....	27
Laser speed .....	27
<b>Layer process .....</b>	<b>18</b>
Licence key .....	6
Material database .....	26
Material process .....	26
Material settings .....	32
<b>Material Template Setup .....</b>	<b>47</b>
<b>Multi Color Option .....</b>	<b>62</b>
<b>Photo optimized process .....</b>	<b>19</b>
<b>Plate setup .....</b>	<b>44</b>
Ppi .....	27
Printer driver .....	10
Printer driver installation .....	5
<b>Process automation .....</b>	<b>65</b>
<b>Process layer .....</b>	<b>67</b>
<b>Process links .....</b>	<b>64</b>
Quick print .....	67
<b>Quick Print activation .....</b>	<b>24</b>
<b>Relief process .....</b>	<b>18</b>
<b>Remote Control .....</b>	<b>53</b>
Resolution .....	19
<b>Resolution Tuner .....</b>	<b>50</b>
<b>Rotary Attachment .....</b>	<b>57</b>
<b>Rotary attachment size .....</b>	<b>16</b>
<b>Seal process .....</b>	<b>19</b>
<b>Service File .....</b>	<b>48</b>
<b>Size Template Setup .....</b>	<b>47</b>
<b>Stamp shoulders .....</b>	<b>61</b>
<b>Standard process .....</b>	<b>17</b>
<b>Tandem Operation .....</b>	<b>54</b>
<b>Unit .....</b>	<b>51</b>
<b>Update Firmware .....</b>	<b>49</b>
Vision .....	91
Vision-Calibration .....	110
<b>Vision-Compensation .....</b>	<b>108</b>

